

ASSEMBLY INSTRUCTIONS FOR YOUR

Jonathan Adler

**CLARDIGE DROP
TABLE LAMP**

ASSEMBLY INSTRUCTIONS:

NOTE: Do not connect the electricity until lamp is fully assembled.

Unpack and place all parts on a soft surface.

1. Remove socket ring (A) from threaded socket (C).
2. Place shade spider (located inside shade (B)) over threaded socket (C).
3. Thread socket ring (A) onto socket (C) to secure shade (B) to lamp.
5. Install light bulb Type A maximum 100 watts.
6. Remove protective plastic (E) from electrical plug (D).
7. Plug lamp into wall outlet.

Caution: To clean, use a soft cloth only. Do not use any chemical or abrasive cleaners.

Note: Turn the power off (unplug from the wall outlet) before replacing the bulb, making sure the bulb has had sufficient time to cool down. Do not subject the lamp to any shock while lit as shattering of bulb may result.

IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce risk of electric shock, this plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted.

DO NOT ALTER THE PLUG.

